

AWARENESS SIGNS**PRODUCT DESCRIPTION**

High visibility graphics on a chemically resistant, high visibility yellow, orange, green or red ABS plastic shell. Promotes awareness of location of your emergency equipment.

COMPONENT LIST

For Top/Bottom or Mid Entry Pipe Mount Signs

1. Two Shells
2. Trim Strip Kit w/Tie Wraps & Positioning Clamp
3. Instruction Sheet

For Wall Mount Signs

1. One Shell
2. Instruction Sheet

SPARE PARTS LIST

P/N 00112901 Trim Strip Kit




FIGURE 1

INSTALLATION INSTRUCTIONS**SHOWER MOUNT INSTALLATIONS**

1. Before affixing to shower, place shells together and match edges evenly. Clamp shells together with vise grips or C-clamps on both sides for ease of trim strip installation.
2. Spread walls of trim strip by curling back before applying to sign as shown in **Figure 1**.
3. Attach the trim strip beginning at the top edge of one side of the shells.
4. Press trim strip on shells firmly to secure. Continue to feed trim strip in this manner over entire length of sign.
5. Place sign shells around upper shower stanchion and close shells.
6. Pass tie wrap through bottom holes of both shells.
7. Pass tie wrap end through closure tab and pull tight.
8. Repeat process through top holes of both shells.
9. Repeat steps 3 and 4 to complete final trim strip assembly. Remove tie wraps if desired. Continue to Positioning Clamp Installation.

POSITIONING CLAMP INSTALLATION

1. Once shells have been installed on shower, affix the positioning clamp to the shower stanchion, below the shells.
2. Adjust shells to the desired height and hand-tighten the positioning clamp, with it flush with bottom of shells.
3. Use pliers or vise grips to further tighten the positioning clamp.

WALL MOUNT INSTALLATIONS

1. Secure half shell to wall using either screws or rivets (supplied by others) through shell edge or holes, or double-sided adhesive tape or appropriate sealant. Apply to flat area (outer flange) for best results.

PROPOSITION 65

WARNING: This product can expose you to BPA, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

WARRANTY STATEMENT

ENCON HEREBY DISCLAIMS ALL WARRANTIES EXPRESSED OR IMPLIED INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD-PARTY RIGHTS, EXCEPT AS HEREINAFTER PROVIDED.

Encon Safety Products warrants that for one year from the date of purchase of any Encon products, the product will be free of defects in materials and workmanship if properly used and cared for or cleaned under normal conditions in accordance with Encon's use and care instructions and properly installed, if applicable, in accordance with Encon's installation instructions. With respect to the product, Encon's only obligation and purchaser's exclusive remedy under this warranty is to repair or replace such product; provided that:

1. Encon is notified of the defect within one year of shipment, and
2. the product is determined by Encon to be defective.

Encon requires proof of original ownership as proof of warranty coverage, and Encon must receive any claim under this Limited Warranty within one year of purchase of the product.

NOTWITHSTANDING ANYTHING TO THE CONTRARY CONTAINED HEREIN, ENCON SHALL NOT BE LIABLE FOR LOSS, DAMAGE, OR EXPENSE ARISING DIRECTLY OR INDIRECTLY AS A CONSEQUENCE OF USE OF THE EQUIPMENT WITH OTHER PRODUCTS OR FROM ANY OTHER CAUSE, INCLUDING ANY CONSEQUENTIAL, INCIDENTAL, SPECIAL OR EXEMPLARY DAMAGES, EXCEPT FOR ENCON'S OBLIGATION TO REPAIR OR REPLACE DEFECTIVE PRODUCTS AS EXPRESSLY PROVIDED IN THIS STATEMENT.

Replacement parts purchased from Encon are warranted for one year following the shipment of such replacement part, or until the expiration of the warranty period for the product, whichever is less. No warranty is given in connection with products that are altered without Encon's expressed written consent. The same warranty limitations and the obligations of Encon as set out herein above shall apply to replacement parts.

Encon's total liability arising out of this warranty (including, but not limited to, warranty claims) regardless of forum and regardless of whether such action or claim is based on tort, contract or otherwise will not exceed the total purchase price of the product.



6825 W. Sam Houston Pkwy. N
Houston, TX 77041
1-800-AT-ENCON / 1-800-283-6266
customerservice@enconsafety.com
<http://www.enconsafety.com>