



**THERMA-FLOW SAFETY SHOWER
STORAGE**

GENERAL INFORMATION

When a Therma-Flow Shower is not in use and needs to be stored, the following guidelines shall be adhered to.

ATTENTION:

Before storing the Therma-Flow shower, ensure that the entire unit has been drained of all fluids.

STORAGE REQUIREMENTS

1. If the unit has been in use, ensure that the junction box is closed and that the screws are tightened to prevent moisture from entering the box and damaging the components.
2. Check to ensure that all unused electrical hubs on the junction box have been plugged.
3. Check to ensure that all valves have been closed (Shower and Eyewash/Facewash)
4. Check to ensure that the inlet supply has been plugged.
5. Return to a new storage crate or the original one if still intact.
6. When storing the unit in an area where the temperature can fluctuate, the ambient air temperature must not exceed the maximum or minimum storage temperature of the components.
7. If possible, store the unit in a climate controlled area that will ensure that the unit is free of moisture and that the temperature is safe for the components.
 - a. Relative Humidity < 95%
 - b. Maximum Storage Temperature: 80°C / 176°F
 - c. Minimum Storage Temperature: -40°C / -40°F
8. If the unit will be stored for an extended period of time, the unit and storage environment must be inspected periodically to ensure that there is no damage to the equipment.

PROPOSITION 65

WARNING: This product can expose you to BPA, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

WARRANTY STATEMENT

ENCON HEREBY DISCLAIMS ALL WARRANTIES EXPRESSED OR IMPLIED INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD-PARTY RIGHTS, EXCEPT AS HEREINAFTER PROVIDED.

Encon Safety Products warrants that for one year from the date of purchase of any Encon products, the product will be free of defects in materials and workmanship if properly used and cared for or cleaned under normal conditions in accordance with Encon's use and care instructions and properly installed, if applicable, in accordance with Encon's installation instructions. With respect to the product, Encon's only obligation and purchaser's exclusive remedy under this warranty is to repair or replace such product; provided that:

1. Encon is notified of the defect within one year of shipment, and
2. the product is determined by Encon to be defective.

Encon requires proof of original ownership as proof of warranty coverage, and Encon must receive any claim under this Limited Warranty within one year of purchase of the product.

NOTWITHSTANDING ANYTHING TO THE CONTRARY CONTAINED HEREIN, ENCON SHALL NOT BE LIABLE FOR LOSS, DAMAGE, OR EXPENSE ARISING DIRECTLY OR INDIRECTLY AS A CONSEQUENCE OF USE OF THE EQUIPMENT WITH OTHER PRODUCTS OR FROM ANY OTHER CAUSE, INCLUDING ANY CONSEQUENTIAL, INCIDENTAL, SPECIAL OR EXEMPLARY DAMAGES, EXCEPT FOR ENCON'S OBLIGATION TO REPAIR OR REPLACE DEFECTIVE PRODUCTS AS EXPRESSLY PROVIDED IN THIS STATEMENT.

Replacement parts purchased from Encon are warranted for one year following the shipment of such replacement part, or until the expiration of the warranty period for the product, whichever is less. No warranty is given in connection with products that are altered without Encon's expressed written consent. The same warranty limitations and the obligations of Encon as set out herein above shall apply to replacement parts.

Encon's total liability arising out of this warranty (including, but not limited to, warranty claims) regardless of forum and regardless of whether such action or claim is based on tort, contract or otherwise will not exceed the total purchase price of the product.



6825 W. Sam Houston Pkwy. N
Houston, TX 77041
1-800-AT-ENCON / 1-800-283-6266
customerservice@enconsafety.com
<http://www.enconsafety.com>